VAV - Single Zone



Features

- Maintaining room temperature within $\pm 1\,\,^\circ C$ depending on environment.
- Use of an on-board temperature sensor.
- User-friendly temperature and clock setting.
- Maximum air control override.
- Manual and programming modes.
- LCD indicator for parameters and status display.
- Programmable minimum ventilation.
- Easy cabling and commissioning.

Zonemaster - Single Zone VAV System

ltem #	Description
657153	Single Zone Touchpad
657155	NEAT 24V Transformer with plug
657186	NEAT Supply Air Sensor c/w 7M lead
657161	Control Cable 7M
Full Kit Product Code:	677187

All sales are made on the basis of the 'Polyaire Terms and Conditions of Trade' ©2016 PolyaireTM Pty Ltd. The manufacturer reserves the right to alter product specifications without notice. E. & O.E. Conditions Apply.